# WAKESHADE

# Clamp Size Chart


## CONTACT US

info@sugarhouse.us

(801) 563-9600 www.SugarHouse.us

7526 S. State St., Midvale, UT 84047


## To determine the right size clamp for your boat follow these steps:

1. Print this page to actual size or 100% scale.
2. Cut out the length chart along the dotted lines.
3. Measure the circumference of the bar where the clamps will attach.
4. Select the clamp size that fits your tower or t-top bar.
5. If the circumference is between two clamp size options, please select the size that is closest to the circumference of your bar.

*If our standard clamp sizes don't work, let us know. We can create the size you need.

## SIZES

The clamps come with inserts used to accommodate a range of tower and t-top bar sizes.

| CLAMP SIZE | 1.25" | 1.375" | 1.5" | 1.625" | 1.75" | 1.875" | 2" | 2.125" | 2.25" | 2.375" | 2.5" | 2.625" | 2.75" | 2.875" | 3" |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| CIRCUMFERENCE | 3.93" | 4.32" | 4.71" | 5.1" | 5.5" | 5.89" | 6.28" | 6.68" | 7.0" | 7.46" | 7.85" | 8.25" | 8.64" | 9" | 9.42" |

## RULER

| | CLAMP SIZE | 1.25" | 1.375" | 1.5" | 1.625" | 1.75" | 1.875" | 2" | 2.125" | 2.25" | 2.375" | 2.5" | 2.625" | 2.75" | 2.875" | 3" |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 0" | CIRCUMFERENCE | 3.93" | 4.32" | 4.71" | 5.1" | 5.5" | 5.89" | 6.28" | 6.68" | 7.0" | 7.46" | 7.85" | 8.25" | 8.64" | 9" | 9.42" |

**PRINTER CHECK:** Measure this box to check accuracy.

2 INCHES